## ≣≣ unidrain®

## PRODUCT SHEET

## Sealing cover | 1890.0000



## SKU 1890.0000 VVS Number 155009900

For testing of the wetroom solution for leaks before laying tiles. Placed in the drain unit. Fill the shower niche with 20-mm water and allow to stand for 24 hours to test the seal.

Sealing cover | 1890.0000 - Sealing cover, line drain - 1890.0000

